

NECK CLAMP ASSEMBLY

1. Disassemble the ratchet on the inside, and move it to the outside.



2. Loosen the two doors at the top and remove the pin at the bottom.



3. Put the doors in the right position and insert the pin at the bottom.



4. Attach the ratchet pipes to the Neck Clamp doors.



7 Theuns Mulder str
P.O Box 995
Brits
0250
(T) 012 250 2188
(F) 012 250 2286

Neck Clamp onto Crush Assembly

